



**NOTES:**

1. TO ASSEMBLE, APPLY A DOUBLE LAYER OF TEFLON TAPE, AND A LAYER OF PIPE DOPE TO THE THREADS ON THE PLASTIC FITTINGS AND INSTALL PER THE MANUFACTURER'S INSTRUCTIONS.
2. ASSEMBLY SHALL BE PRESSURE TESTED.

12/17/2016 - 5:57:30pm



**THE CITY OF LYNCHBURG**

LPFM - LATERAL

SCALE:  
NOT TO SCALE

DETAIL #  
**27.33**

REVISION DATE:  
12-15-2016

SHEET #:  
1 OF 1

USE WITH THE CITY OF LYNCHBURG STANDARD SPECIFICATIONS ONLY